



INSTRUCTIONS FOR THE 1993 COBRA STYLE GRILLE INSERT

1. TRIM PROVIDED TEMPLATE FROM INSTRUCTIONS.
2. TAPE THE TEMPLATE TO THE PASSENGER SIDE OF THE BUMPER COVER.
3. TRACE AREA TO BE CUT OUT OF BUMPER COVER WITH A MARKER.
4. REMOVE TEMPLATE AND TAPE TO THE DRIVER SIDE OF THE BUMPER COVER.
5. TRACE AREA TO BE CUT OUT OF BUMPER COVER WITH A MARKER.
6. CAREFULLY!!! CUT THE BUMPER COVER ALONG THE LINES THAT WERE TRACED FROM THE TEMPLATE. MAKE SMALL CUTS AND TRIM AS NEEDED.
CUTTING TOO MUCH MATERIAL FROM THE BUMPER COVER WILL COMPROMISE ITS INTEGRITY AND NOT LEAVE ENOUGH MATERIAL FOR INSERT TO ADHERE!
7. ON THE INSERT THERE IS A SMALL STUD LOCATED ON THE DRIVERS SIDE. YOU MUST DRILL OUT A HOLE IN YOUR BUMPER COVER OR SHAVE IT OFF TO COMPENSATE.
8. SCUFF, PRIME AND PAINT INSERT.
9. TAKE NOTE WHERE THE THREADED STUD IS MOUNTED ON THE COBRA GRILLE. MARK THE SPOT WHERE THE THREADED STUD TOUCHES THE BUMPER COVER AND DRILL ¼ INCH HOLE.
10. INSTALL TO HEADER PANEL THROUGH HOLES IN BACK SIDE (HARDWARE NOT INCLUDED)
11. CLEAN AREA WHERE THE COBRA GRILLE INSERT MEETS THE BUMPER COVER WITH ALCOHOL.
12. CAREFULLY!!! POSITION AND APPLY COBRA GRILLE INSERT TO BUMPER COVER. APPLY GENTLE PRESSURE WITH YOUR HAND TO SMOOTH INSERT AND EVENLY APPLY TAPE.
13. INSTALL THE STUD OF THE GRILLE PONY THROUGH THE INSERT AND INTO THE BUMPER COVER.
14. INSTALL AND TIGHTEN NUT FOR PONY ON THE BACKSIDE OF THE BUMPER COVER. DO NOT OVERTIGHTEN!

