



WMS Catch Can Oil Separator Installation - Universal Kit

- Find a suitable mounting point for the catch can. Attach the bracket to can using 4 allen head screws and washers provided.
- The 90 degree AN fittings push into the rubber hose and screw onto the catch can fittings. Optional straight and 45 fittings are also available if required.
- T's have been provided that may assist in hookup to engine but other fittings may be required
- Hose can be used to extend the drain to an accessible location.
- Hook up to engine as shown in diagram below.



Use shrink wrap to secure the check valve into hose. Be sure arrow is pointing toward engine and cover both hoses with shrink wrap.

